KONIG & MEYER 14330 SAXOPHONE ALTO STAND BLACK



45,00 € tax included

Reference: KM14330

KONIG & MEYER 14330 SAXOPHONE ALTO STAND BLACK

Practical, easy to use and stable stand for Eb alto saxophones. Solid square-type aluminum tubes with a large central locking screw, protective rubber bumps where the stand connects with the saxophone body and the bell. Embedded foot end caps. Folds compactly, can be transported in the supplied velour bag in the saxophone bell.

Data:
- Adjustment: central locking screw
- Height: 310 mm
- Instrument support: non-marring plastic material
- Material: aluminum
- Special features: folds very small' easy-to-use' can be transported in the supplied velour bag in the saxophone bell' embedded foot end caps
- Suitable for: Eb alto saxophones
- Type: black
- Weight: 0.276 kg